

BT2000 Belt Tear and Spillage Detector

Because belt tears normally occur over the length of a conveyor it is very difficult to detect. When a belt tear occurred, the weight of the material causes the tear to open and the material will spill through the cut. The BT2000 has been designed and developed to catch the spilling material in the basket. The weight of the material in the basket will cause the basket to tilt backwards and a limit switch under the basket will make or break a contact that is used to stop the conveyor.

BRAMCO ELECTRONICS Product Shee

Features

- Maintenance free
- Easy to install
- Adjustable width and height
- **Concealed Wiring**
- Quick to Clean and Reset
- Available in Stainless

Specifications

Contacts: Contacts Operation: Contacts Material: Contact Rating: Ingress Protection: Trip Weight: Approx: Material: Corrosion Protection: Cable Length: **Operating Temperature**

Ordering Information

Part No Mil	d Steel Plated:	
Part No Sta	ainless	

Snap Action Silver Plated 1.5A @ 240VAC IP65 1.5Kg Mild Steel or S/Steel Plated 5m -25 to 70°C

1xNO & NC

S11514 S11515

Basket

Resetting

ket backwards.

Basket Retainer

ping the basket over

Width Adjustment


The basket is equipped with a grid base to avoid nuisance trips from dust that could collect at the base.

ing the spring steel retaining clip forward and tilting the bas-

The spring steel basket retain-

to avoid strong winds from flip-

The end clamps makes the



mounting width of the unit adjustable for ease of installation.

Height Ajustment

Side mounting brackets are designed to be attached to unistrut upright posts to enable height adjustment of the unit.

Concealed Wiring All wiring is concealed inside the structure frame for protection against the moving conveyor belt.

Trip Switch

IP65 with a rubber boot for protection against water, dust, and mud




BRAMCO ELECTRONICS (Pty) Ltd 3 Hospital Road Ext.2, Delmas PO Box 616, Delmas, 2210 South Africa

Contact Details, South Africa +27 13 665 5288 / 1376 Tel: Fax: +27 13 665 5287 E-mail: sales@bramco.co.za Website: www.bramco.co.za

Contact Details, Australia Tel: +61 2 4014 4444 +61 2 4967 4100 Fax: E-mail: sales@bramco.com.au Website: www.bramco.com.au

Copyright Bramco Electronics pecifications subject to change without notice July 2012



BRAMCO ELECTRONICS (Pty) Ltd 3 Hospital Road Ext.2, Delmas PO Box 616, Delmas, 2210 South Africa

Copyright Bramco Electronics

Tel: Fax: E-mail: Website: Specifications subject to change without notice July 2012

Contact Details, South Africa +27 13 665 5288 / 1376 +27 13 665 5287 sales@bramco.co.za www.bramco.co.za

Contact Details, Australia +61 2 4014 4444 Tel: Fax: +61 2 4967 4100 E-mail: sales@bramco.com.au Website: www.bramco.com.au